



KELLETT ENTERPRISES, INC.

INSTRUCTIONS FOR INSTALLING LP-13 SHAKE ABSORBER® ISOLATION AND VIBRATION PADS

1. If there are old pads present remove old pads and clean floor surface thoroughly using a mild cleaning product. Do not use a lacquer or paint thinner. Use a wire brush or sharp edge item, when necessary, in order to obtain a clean, smooth surface on wooden or concrete floors. Floors should be clean and dry before installing vibration and isolation pads.
2. In most instances it is not necessary to glue the pads. If desirable to glue, use our KE-Sure Stick Adhesive. Cover both sides of the pad, the floor and then the machinery foot with a **very thin coating**. Allow the glue to dry to touch, (approximately three to five minutes). If the adhesive is “tacky” it is ready to be mounted to the machine foot and the floor area. Be sure to place the machine foot in the middle of the pad...allowing the required ½” overhang on all 4 sides of the pad.
3. **CAUTION:** Do not use adhesive that becomes brittle and do not saturate or cover the pad with excessive amount of adhesive. If the above instructions are followed by using our KE-Sure Stick Adhesive with a very thin coating, you will get the best results for your installation.

Please do not hesitate to call us if you have any questions regarding the correct installation for our LP-13 Shake Absorber® Vibration and Isolation Pads.

KELLETT ENTERPRISES, INC.

201 Beverly Road

Greenville, South Carolina 29609

Telephone: 864-244-7248

Fax: 864-292-8612